

## How to Setup PureVPN Manually on Asus (PPTP)

### Things to Consider:


Before you begin, please make sure that:

- You have a working internet connection
- A Supported Router.
- A Premium PureVPN account (if you haven't bought it yet, [click here](#) to buy)

1 Access your Router Panel and Click on VPN from Left menu.




2 From VPN Section, Click on VPN Client then click on “Add profile”




3 Under PPTP insert the following info:


- Description: PureVPN, PureVPN US, PureVPN UK etc (Anything you like)
- VPN Server: Insert any server, [click here](#) to get the server list
- Username: Insert Username provided by PureVPN
- Password: Insert Password provided by PureVPN
- PPTP Options: Auto (For Streaming purpose select None)
- Click OK



4 Click on "Activate" to connect VPN



5 VPN connection will be established in few seconds.



[Wouter](#) — A Router with Built-In Security & Accessibility. Get It Now!