

## How to Configure PureVPN on TRENDNET?

### Things to Consider:

Before you begin, please make sure that:

- You have a working internet connection
- VPN Supported Router.
- Own a premium PureVPN account (If you do not already own one, you can buy a subscription from [here](#))

Here is a simple step-by-step guide on how you can configure PureVPN on a Trendnet router using PPTP protocol.

Enter or copy-paste <http://192.168.10.1> into your web browser. Your router will ask you to enter your username and password. Use the default credentials and hit "Login".

Default username: admin


Default password: admin

Next, click "Advanced" on the menu present on the left-hand side of your screen.

Now, click "Administration" right below "Advanced" and then click on the "Setup" sub-tab.

Once you enter the "Setup" tab, you will need to manually modify settings for the connection. Here is how to do it:

- Connection Type: From the drop-down menu select "PPTP"
- PPTP Server: Enter the address of your desired VPN server [click here](#) to get the server list:
- The protocol of Physical Connection: Select "DHCP"
- DNS Servers: In the first box "8.8.8.8" and in the second box, "208.67.222.222"
- Username: Enter your username provided by PureVPN
- Password: Enter your password provided by PureVPN
- On-Demand Mode: Select "Disabled"
- Keep Alive Mode: Select "Enabled"
- MTU: Type "1452"



And there you go! Enjoy complete internet freedom.